

LOCKING

1. Touch the lock to wake it up
2. Hold your card over the lock until it locks



OPENING

1. Touch the lock to wake it up
2. Hold your card over the lock until it opens

LOCKS WILL OPEN 24H AFTER LOCKING

Locks work with most bank, bus and library cards, and other cards that have 13,56 MHz RFID tag in them.